

NOTES

- 1. RAMPING TO BE USED AFTER BINDER IS CONSTRUCTED AND UNTIL FINAL SURFACE COURSE IS PLACED.
- 2. MANHOLES TO BE RAMPED NO LATER THAN NOVEMBER 1ST.
- 3. RAMPS TO BE MAINTAINED THROUGHOUT THE WINTER BY DEVELOPER.
- 4. RAMP MATERIAL TO BE REMOVED BY MILLING OR OTHERWISE REMOVED BEFORE PLACEMENT OF FINAL SURFACE COURSE.

MIX DESIGN FOR EMERGENCY RAMP PATCHING COMPOUND

MIX:

40% QUICKCRETE HYDRAULIC CEMENT 60% MORTAR MIX ENOUGH WATER TO MAKE IT WORKABLE (TOO MUCH WATER WILL GREATLY LENGTHEN SET TIME)

Revised: 1. 06/12/2015 2. 3. 4.

Drawing Name

TEMPORARY MANHOLE AND CURB RAMPING Drawing Number

RD-07

AW

Date: 05/19/2015

Drawn Checked

JH

